


DeChiaro College Center 012  
Knott Hall 005, 006, 305, 309, B01, B03  
*Shelf Equipment*



**VCR/DVD PLAYER:**

The VCR and DVD PLAYER are the only devices located on the shelf that can be controlled via the remote at the podium. If you wish to play a VHS cassette, be sure the main system is on (select "ON" under "SYSTEM" on the Crestron remote), insert the video in the VHS slot, select "VCR" as the source on the remote, and then hit "PLAY", located under "FUNCTIONS" on the remote control. For a DVD, insert the DVD into the DVD tray, select "DVD" as the source, then press "PLAY" under "FUNCTIONS" on the remote.