


Knott Hall 007, 009

Shelf Equipment



VCR:

The VCR is the only device located on the shelf that can be controlled via the remote at the podium. If you wish to play a VHS cassette, be sure the main system is on (select "ON" under "Projector Power" on the AMX remote), insert the video in the VHS slot, select "VHS" under "SELECT", and then hit "PLAY", located under "FUNCTIONS" on the remote control.